Instructional Guide

Wireless Smart Keypad

Bluetooth Pairing

1. Turn the power switch On

2. Select type of the device

Set **Mac / PC** switch before pairing to appropriate device.

3. Press the Connect Button

Press the **Connect** button on the back of the keypad for 3 seconds. The LED light will blink green.

ON OFF

Mac PC

Conn.

4. Run Bluetooth Setup Assistant

Turn on Bluetooth on your device and run Bluetooth Setup Assistant.

5. Find and select keypad

Select **"ST-WKP31"** from the list and click continue to proceed with setup.

6. Enter passkey on keypad

Your device will generate a passkey. While in "keypad mode", type it on the keypad, and press enter to finish pairing.

1234 5678

If you like our product, please consider writing a review on **amazon.com**!

Do you have concerns or questions? Get in touch with us!

Phone: (858) 268 1800
Email: support@satechi.com