



Dimension: 108 × 108 mm

OUTSIDE

<p>NEED HELP? BESOIN D'AIDE? ¿NECESITAS AYUDA? BRAUCHST DU HILFE? Den USB-C-Stecker in die Aussparung einsetzen Inserire il connettore USB-C nell'incavo USB-Cコネクタを切り欠きに差し込んでください 케이블을 정렬 핀 바로 뒤의 채널에 놓으십시오 將線纜放入對齊柱后面的槽道中</p> <p>Manufacturer: 7365 Mission Gorge Rd., Ste. G San Diego, CA 92120, USA +1 858 268 1800 support@satechi.net www.satechi.net</p> <p>EU Authorized Representative: Chemical Inspection and Regulation Service Limited CIRS, Regus Harcourt Centre Dublin, Ireland, D02 HW77 +353 1 477 3710</p> <p>UK Representative: Chemical Inspection and Regulation Service UK Ltd. Unit 536, Salisbury House London Wall, London, EC2M 5SQ +44 20 3289 6395</p> <p>ST-GOTGFC_OTG_StandHub_UM_RevA</p>	<p>CABLE STORAGE RANGEMENT DU CÂBLE ALMACENAMIENTO DEL CABLE KABELAUFBEWAHRUNG CONSERVAZIONE DEL CAVO ケーブル収納 케이블 보관 線纜存放</p> <p>1. Place the cable into the channel right after the alignment post Placez le câble dans la rainure juste après le taquet d'alignement Colocar el cable en el canal justo después del poste de alineación Das Kabel direkt hinter dem Ausrichtungsstift in den Kanal legen Posizionare il cavo nella scanalatura subito dopo il perno di allineamento ケーブルをアライメントポストのすぐ後ろの溝に置いてください 케이블을 정렬 핀 바로 뒤의 채널에 놓으십시오 將線纜放入對齊柱后面的槽道中</p> <p>2. Fit the USB-C connector into the cutout Insérez le connecteur USB-C dans l'encoche Encajar el conector USB-C en la abertura Den USB-C-Stecker in die Aussparung einsetzen Inserire il connettore USB-C nell'incavo USB-Cコネクタを切り欠きに差し込んでください USB-C 커넥터를 컷아웃에 맞추어 끼우십시오 將 USB-C 接口插入開口處</p> <p>3. Press the cable into the channel all the way around Appuyez sur le câble dans la rainure tout autour Presionar el cable en el canal alrededor de todo el perímetro Das Kabel rundum in den Kanal drücken Premere il cavo nella scanalatura su tutto il perimetro ケーブルを溝に沿ってぐるっと押し込んでください 케이블을 채널에 따라 전체적으로 눌러 넣으십시오 將線纜沿槽道全部按壓到底</p> <p>4. Make sure it sits flat, then close the stand Assurez-vous que le câble est à plat, puis refermez le support Asegúrese de que esté plano, luego cierre el soporte Stellen Sie sicher, dass es flach liegt, und schließen Sie dann den Ständer Assicurarsi che sia appoggiato piatto, quindi chiudere il supporto ケーブルが平らに収まっていることを確認してから、スタンドを閉じてください 케이블이 평평하게 놓였는지 확인한 후 스탠드를 닫으십시오 確保線纜平整放置, 然后关闭支架</p>	<p>IMPORTANT IMPORTANT IMPORTANTE WICHTIG IMPORTANTE 重要 중요 重要</p> <p>• Host devices must support Power Delivery and DP Alt Mode over USB-C for full functionality.</p> <ul style="list-style-type: none"> Les appareils hôtes doivent prendre en charge Power Delivery et le mode DP Alt via USB-C pour une fonctionnalité complète. Los dispositivos host deben soportar Power Delivery y DP Alt Mode a través de USB-C para funcionalidad completa. Host-Geräte müssen Power Delivery und DP Alt Mode über USB-C für volle Funktionalität unterstützen. I dispositivi host devono supportare Power Delivery e DP Alt Mode tramite USB-C per una funzionalità completa. ホスト機器はUSB-C経由でPower DeliveryとDP Alt Modeをサポートする必要があります(フル機能対応のため)。 호스트 장치는 완전한 기능을 위해 USB-C를 통한 Power Delivery 및 DP Alt Mode를 지원해야 합니다. 主机设备必须支持通过USB-C的电力传输(Power Delivery)和DP Alt模式,方可实现全部功能。 <p>• USB-C data port does not support video output or output charging.</p> <ul style="list-style-type: none"> Le port de données USB-C ne prend pas en charge la sortie vidéo ni la charge en sortie. El puerto de datos USB-C no soporta salida de vídeo ni carga de salida. Der USB-C-Datenanschluss unterstützt keine Videoausgabe oder Ausgangsladung. La porta dati USB-C non supporta l'uscita video né la ricarica in uscita. USB-C 데이터 포트는映像出力や出力充電をサポートしていません。 USB-C 데이터 포트는 비디오 출력 또는 출력 충전을 지원하지 않습니다. USB-C 数据端口不支持视频输出或输出充电。 	<p>• Not compatible with Apple USB SuperDrive or other CD Readers.</p> <ul style="list-style-type: none"> Non compatible avec Apple USB SuperDrive ou autres lecteurs de CD. No compatible con Apple USB SuperDrive ni otros lectores de CD. Nicht kompatibel mit Apple USB SuperDrive oder anderen CD-Laufwerken. Non compatibile con Apple USB SuperDrive o altri lettori CD. Apple USB SuperDriveやその他のCDリーダーには対応していません。 Apple USB SuperDrive 및 기타 CD 리더기와 호환되지 않습니다. 不兼容 Apple USB SuperDrive 或其他 CD 读取器。 连接的USB设备输入电流不应超过5V/900 mA。 <p>• Direct HDMI to HDMI connection required for video output.</p> <ul style="list-style-type: none"> Une connexion HDMI directe de port à port est requise pour la sortie vidéo. Se requiere conexión HDMI directa para salida de vídeo. Für die Videoausgabe ist eine direkte HDMI-zu-HDMI-Verbindung erforderlich. Per l'uscita video è richiesta una connessione HDMI diretta. 映像出力にはHDMIとHDMIの直接接続が必要です。 비디오 출력에는 HDMI와 HDMI 간 직접 연결이 필요합니다. 视频输出需要直接的HDMI至HDMI连接。 <p>• Not compatible with thick tablet cases.</p> <ul style="list-style-type: none"> Non compatible avec les étuis épais pour tablettes. No compatible con fundas gruesas para tabletas. 	<ul style="list-style-type: none"> Nicht kompatibel mit dicken Tablet-Hüllen. Non compatible con custodie spesse per tablet. 厚いタブレットケースには対応していません。 두꺼운 태블릿 케이스와 호환되지 않습니다. 不兼容厚款平板保护壳。 	<p>S A T E C H I</p> <p>ONTHEGO FOLDABLE STAND HUB ONTHEGO SUPPORT À PLIANT AVEC HUB</p>  <p>USER MANUAL Manuel de l'utilisateur Manual de usuario Benutzerhandbuch Manuale utente ユーザーマニュアル 사용자 설명서 用户说明</p>
---	---	---	---	---	--

INSIDE

<p>PLUG & PLAY CONNECTER ET UTILISER CONEXIÓN Y USO ANSCHLIEßEN UND VERWENDEN COLLEGARE E USARE 接続して使用する 연결하여 사용하십시오 连接并使用</p> <p>1. Connect the USB-C cable to your iPad Branchez le câble USB-C à votre iPad Conectar el cable USB-C a su iPad USB-C-Kabel mit Ihrem iPad verbinden Collegare il cavo USB-C al tuo iPad USB-C케이블을iPad에 연결하십시오 將 USB-C 線纜连接到您的 iPad</p> <p>2. Connect your devices Branchez vos appareils Conectar sus dispositivos Geräte verbinden Collegare i dispositivi デバイスを接続してください 기기를 연결하십시오 连接您的设备</p>	<p>FUNCTIONS FONCTIONS FUNCIONES FUNKTIONEN FUNZIONI 機能 기능 功能</p> 	<p>1. 3.5mm Audio Jack (Input/Output supported) Prise audio 3,5 mm (entrée/sortie prise en charge) Jack de audio de 3,5 mm (soporta entrada/salida) 3,5-mm-Audioanschluss (Eingang/Ausgang unterstützt) Jack audio da 3,5 mm (soporta ingresso/uscita) 3,5 mmオーディオジャック (入力/出力対応) 3,5 mm 오디오 잭 (입력/출력 지원) 3.5毫米音频接口 (支持输入/输出)</p> <p>2. USB-C PD Port (100W Input) (85W Output) Port USB-C PD (entrée 100 W) (sortie 85 W) Puerto USB-C PD (entrada 100W) (salida 85W) USB-C PD-Anschluss (100 W Eingang) (85 W Ausgang) Porta USB-C PD (ingresso 100 W) (uscita 85 W) USB-C PD 포트 (100 W 입력) (85 W 출력) USB-C PD接口 (100 W输入) (85 W输出)</p> <p>3. HDMI Port (4K/60Hz) Port HDMI Puerto HDMI HDMI-Anschluss Porta HDMI HDMI 포트 HDMI接口</p> <p>4. USB-A Port (Up to 10Gbps) Port USB-A (jusqu'à 10 Gbps) Puerto USB-A (hasta 10 Gbps) USB-A-Anschluss (bis zu 10 Gbps) Porta USB-A (fino a 10 Gbps) USB-A 포트 (최대 10Gbps) USB-A接口 (最高 10Gbps)</p> <p>5. USB-C Port (Up to 10Gbps) Port USB-C (jusqu'à 10 Gbps) Puerto USB-C (hasta 10 Gbps) USB-C-Anschluss (bis zu 10 Gbps) Porta USB-C (fino a 10 Gbps) USB-C 포트 (최대 10Gbps) USB-C接口 (最高 10Gbps)</p>	<p>6. SD and microSD Card Readers (UHS-II) (Up to 312MB/s) Lecteurs de cartes SD et microSD (UHS-II) (jusqu'à 312 Mo/s) Lectores de tarjetas SD y microSD (UHS-II) (hasta 312 MB/s) SD- und microSD-Kartenleser (UHS-II) (bis zu 312 MB/s) Lettori di schede SD e microSD (UHS-II) (fino a 312 MB/s) SDおよびmicroSDカードリーダー (UHS-II) (最大312 MB/s) SD 및 microSD 카드 리더기 (UHS-II) (최대 312 MB/s) SD 和 microSD 读卡器 (UHS-II) (最高312 MB/s)</p> <p>7. USB-C Host Cable (Stored in cable compartment) Câble hôte USB-C (rangé dans le compartiment à câbles) Cable host USB-C (almacenado en el compartimento para cables) USB-C-Hostkabel (im Kabelfach verstaut) Cavo host USB-C (riposto nel vano cavi) USB-C 호스트케이블 (케이블-수납부에 수납) USB-C 호스트 케이블 (케이블 컴파트먼트에 보관됨) USB-C 主机线纜 (存放于线纜盒)</p>	<p>FCC Statement This device complies with part 15 of the FCC results. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>CE DECLARATION OF CONFORMITY Satechi declares that this product is in compliance with the essential requirements and other relevant provisions of applicable EC directives. For Europe, a copy of the Declaration of Conformity for this product may be obtained by visiting https://satechi.net/support/doc</p> <p>WEEE Information According to the WEEE (Waste Electrical and Electronic Equipment) Directive, do not dispose of this product as household waste or commercial waste. Waste electrical and electronic equipment should be appropriately collected and recycled as required by practices established for your country. For information on recycling of this product, please contact your local authorities, your household waste disposal service, or the shop where you purchased the product.</p> <p>CAN ICES(B)/NMB(B) This Class B digital apparatus complies with Canadian ICES(B). (Cet appareil numérique de la Classe B conforme à la norme NMB(B) du Canada).</p>	<p>AUSTRALIAN CONSUMER LAW Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.</p> <p>ONTHEGO 可折叠支架集线器 MODEL 型号: MN25ST104</p> <p>FR ÉLÉMENTS D'EMBALLAGE</p> <p>FR Cet appareil se recycle À DÉPOSER EN MAGASIN À DÉPOSER EN DÉCHÈTERIE Points de collecte sur www.quefairede mesdechets.fr Privilégiez la réparation ou le don de votre appareil !</p>
--	--	--	--	---	---