


Dimension: 75 x 130 mm

OUTSIDE



This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference and
2. This device must accept any interference received, including interference that may cause undesired operation.
Note: This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
1.1. Reorient or relocate the receiving antenna
1.2. Increase the separation between the equipment and receiver
1.3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
1.4. Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.



Satechi declares that this product is in compliance with the essential requirements and other relevant provisions of applicable EC directives. For Europe, a copy of the Declaration of Conformity for this product may be obtained by visiting <https://satechi.net/support/doc>



According to the WEEE (Waste Electrical and Electronic Equipment) Directive, do not dispose of this product as household waste or commercial waste. Waste electrical and electronic equipment should be appropriately collected and recycled as required by practices established for your country. For information on recycling of this product, please contact your local authorities, your household waste disposal service, or the shop where you purchased the product.

CAN ICES-003 (B)/NMB-003(B)
This Class B digital apparatus complies with Canadian ICES-003.
(Cet appareil numérique de la Classe B conforme à la norme NMB-003 du Canada).

Your goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

NEED HELP?

BESOIN D'AIDE? | ¿NECESITA AYUDA? | BENÖTIGEN SIE HILFE? | HAI BISOGNO DI AIUTO? | YARDIMA MI İHTİYACINIZ VAR? | POTRZEBUJĘ POMOCY? | PRECISA DE AJUDA? | НУЖНА ПОМОЩЬ? | 助けが必要ですか? | 도움이 필요하십니까? | 需要幫助? | 需要幫助?

Manufacturer:
7365 Mission Gorge Rd. Ste. G
San Diego, CA 92120, USA
+1 858 268 1800
support@satechi.com
www.satechi.net

EU Authorized Representative:
Chemical Inspection and Regulation
Service Limited
CIRS, Regus Harcourt Centre
Dublin, Ireland, D02 HW77
+353 1 477 3710

UK Representative:
Chemical Inspection and Regulation
Service UK Ltd.
Unit 536, Salisbury House
London Wall, London, EC2M 5SQ
+44 20 3289 6395

S A T E C H I

USB-C COMBO HUB FOR DESKTOP USER MANUAL




Manuel de l'utilisateur | Manual de usuario |
Benutzerhandbuch | Manuale utente | Kullanım kılavuzu |
Instrukcja obsługi | Manual de usuário |
Руководство пользователя | ユーザーマニュアル |
사용자 매뉴얼 | 使用者說明 | 用戶說明

INSIDE

PLUG & PLAY

BRANCHEZ & JOUEZ | CONECTAR Y USAR | STECKEN & SPIELEN
| COLLEGARE E GIOCARE | TAK VE ÇALIŞTIR | PODŁĄCZ I UŻYWAJ
| CONECTE E USE | ПОДКЛЮЧИ И РАБОТАЙ | フラグ&プレイ |
플러그 앤 플레이 | 即插即用 | 即插即用



1. Connect to a laptop or computer


Connexion à un ordinateur portable ou à un ordinateur | Conectar a un portátil u ordenador | Anschluss an einen Laptop oder Computer | Collegare a un laptop o a un computer | Bir dizüstü bilgisayar veya bilgisayara bağlanın | Połączenie z laptopem lub komputerem | Ligar a um computador portátil ou computador | Подключите к ноутбуку или компьютеру | 랩탑또는 컴퓨터에 연결 | 連接筆記型電腦或計算機 | 连接笔记本电脑或计算机

2. Connect your devices

Connectez vos appareils | Conecte sus dispositivos | Schließen Sie Ihre Geräte an | Collega i tuoi dispositivi | Cihazlarınızı bağlayın | Podłącz swoje urządzenia | Conecte seus dispositivos | Подключите свои устройства | お使いのデバイスを接続 | 기기 연결 | 连接到您的裝置 | 连接到您的设备

FUNCTIONS

FONCTIONS | FUNCIONES | FUNKTIONEN | FUNZIONI | FONKSİYONLAR
| FUNKCJE | FUNÇÕES | ФУНКЦИИ | 機能 | 기능 | 功能 | 功能



1. Micro SD Card Slot (UHS-I)

Emplacement pour Carte Micro SD | Ranura para Tarjeta Micro SD | Micro-SD-Kartensteckplatz | Slot per Scheda Micro SD | Micro SD Kart Yuvası | Czytnik Kart Micro SD | Slot para Cartão Micro SD | Слот Для Micro SD-Карты | Micro SD 카드 슬롯 | Micro SD 카드 슬롯 | Micro SD卡插槽 | Micro SD卡插槽

2. SD Card Slot (UHS-I)

Emplacement pour Carte SD | Ranura para Tarjeta SD | SD-Kartensteckplatz | Slot per Scheda SD | SD Kart Yuvası | Czytnik Kart SD | Slot para Cartão SD | Слот Для SD-Карты | SD 카드 슬롯 | SD 카드 슬롯 | SD卡插槽 | SD卡插槽

3. 3X USB-A Data Ports (5Gbps)

Ports de Données USB-A | Puertos de Datos USB-A | USB-A Datenanschlüsse | Porte Dati USB-A | USB-A Data Portları | Porty Danych USB-A | Portas de Dados USB-A | Порты Передачи Данных USB-A | USB-A 데이터 포트 | USB-A 데이터 포트 | USB-A 資料連接埠 | USB-A 数据端口

4. USB-C Connector

Connecteur USB-C | Conector USB-C | USB-C-Anschluss | Connettore USB-C | USB-C Konektörü | Złącze USB-C | Conector USB-C | Разъем USB-C | USB-C コネクタ | USB-C 커넥터 | USB-C连接器 | USB-C连接器

IMPORTANT

IMPORTANT | IMPORTANTE | WICHTIG | IMPORTANTE | ÖNEMLİ
| WAŻNY | IMPORTANTE | ВАЖНО | 重要 | 중요한 | 重要訊息 | 重要信息

• SD and Micro SD card slots cannot be used simultaneously.

• Les fentes pour cartes SD et Micro SD ne peuvent pas être utilisées simultanément.

• Las ranuras para tarjetas SD y Micro SD no se pueden usar simultáneamente.

• SD- und Micro-SD-Kartensteckplätze können nicht gleichzeitig verwendet werden.

• Gli slot per schede SD e Micro SD non possono essere utilizzati contemporaneamente.

• SD ve Micro SD kart yuvaları aynı anda kullanılamaz.

• Gniazda kart SD i Micro SD nie mogą być używane jednocześnie.

• Slots de cartão SD e Micro SD não podem ser usados simultaneamente.

• Слоты для карт SD и Micro SD нельзя использовать одновременно.

• SDとマイクロSDカードスロットを同時に使用することはできません。

• SD 및 Micro SD 카드 슬롯은 동시에 사용할 수 없습니다.

• SD和Micro SD卡插槽不能同时使用。

• SD和Micro SD卡插槽不能同时使用。