

Dimension: 75 x 135 mm

OUTSIDE

- USB-A 포트는 Apple USB SuperDrive 또는 기타 CD 리더와 호환되지 않습니다.
- USB-A 端口與 Apple USB SuperDrive 或其他 CD 讀取器不兼容。
- USB-A 端口与 Apple USB SuperDrive 或其他 CD 读取器不兼容。
- SD and MicroSD slots cannot be used simultaneously.
- Les emplacements SD et MicroSD ne peuvent pas être utilisés simultanément.
- Las ranuras SD y MicroSD no se pueden utilizar simultáneamente.
- SD- und MicroSD-Steckplätze können nicht gleichzeitig verwendet werden.
- Gli slot SD e MicroSD non possono essere utilizzati contemporaneamente.
- SD ve MicroSD yuvaları aynı anda kullanılamaz.
- Gniazda SD i MicroSD nie mogą być używane jednocześnie.
- Os slots SD e MicroSD não podem ser usados simultaneamente.
- Слоты SD и MicroSD нельзя использовать одновременно.
- SD 슬롯과 MicroSD 슬롯을 동시에 사용하는 것은 불가능합니다.
- SD 및 MicroSD 슬롯은 동시에 사용할 수 없습니다.
- SD 和 MicroSD 插槽不能同时使用。
- SD 和 MicroSD 插槽不能同时使用。



This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference and
2. This device must accept any interference received, including interference that may cause undesired operation.
Note: This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
1.1. Reorient or relocate the receiving antenna
1.2. Increase the separation between the equipment and receiver
1.3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
1.4. Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the manufacturer could void the user's authority operate the equipment.



Satechi declares that this product is in compliance with the essential requirements and other relevant provisions of applicable EC directives. For Europe, a copy of the Declaration of Conformity for this product may be obtained by visiting www.satechi.net/doc



According to the WEEE (Waste Electrical and Electronic Equipment) Directive, do not dispose of this product as household waste or commercial waste. Waste electrical and electronic equipment should be appropriately collected and recycled as required by practices established for your country. For information on recycling of this product, please contact your local authorities, your household waste disposal service, or the shop where you purchased the product.

CAN ICES-3 (B) / NMB-3 (B)
This Class B digital apparatus complies with Canadian ICES-3003.
(Cet appareil numérique de la Classe B conforme à la norme NMB-003 du Canada)



NEED HELP?

BESOIN D'AIDE POUR? | ¿NECESITA AYUDA? | BRAUCHEN SIE HILFE?
| HAI BISOGNO DI AIUTO? | YARDIMA MI İHTİYACINIZ VAR? |
| POTRZEBUJĘ POMOCY? | PRECISO DE AJUDA? | НУЖНА ПОМОЩЬ?
| 助けが必要? | 도움이 필요하다? | 需要幫忙? | 需要幫忙?

Manufacturer:
7365 Mission Gorge Rd. Ste. G
San Diego CA 92120 USA
+1 858 268 1800
support@satechi.com
www.satechi.net

UK Representative:
CMS Distribution Ltd.
CasOne Freeway Drive
CASTLEFORD W Yorkshire
WF10 5EJ, United Kingdom
+44 20 8962 2500
EORI: GB117202262000



Authorized Representative:
QIMA EUROPE AR GmbH
Schleidenstraße 1
22083 Hamburg
GERMANY

S A T E C H I

TYPE-C USB 3.0 3-IN-1 COMBO HUB USER MANUAL




Manuel d'utilisateur | Manual de usuario |
Bedienungsanleitung | Manuale dell'utente | Kullanım
kılavuzu | Instrukcja obsługi | Manual do usuário |
Руководство пользователя | ユーザーマニュアル |
사용 설명서 | 用戶手冊 | 用戶手冊

INSIDE

PLUG & PLAY

BRANCHEZ & JOUEZ | CONECTAR Y USAR | STECKEN & SPIELEN | COLLEGARE E GIOCARE | TAK VE ÇALIŞTIR |
PODŁĄCZ I UŻYWAJ | CONECTE E USE | ПОДКЛЮЧИ И РАБОТАЙ | プラグ&プレイ | 플러그 앤 플레이 | 即插即用 | 即插即用



1. Connect to a laptop


Connectez-le à un ordinateur portable | Conéctelo a un ordenador portátil | Schließen Sie es an einen Laptop an | Collegalo a un laptop | Bir dizüstü bilgisayara bağlayın | Podłącz go do laptopa | Подключите его к ноутбуку | ラップトップに接続します | 노트북에 연결해 보세요 | 连接到笔记本电脑 | 连接到笔记本电脑

2. Connect your devices

Connectez vos appareils | Conecte sus dispositivos | Verbinden Sie Ihre Geräte | Connetti i tuoi dispositivi | Cihazlarınızı bağlayın | Podłącz swoje urządzenia | Conecte seus dispositivos | Подключите свои устройства | デバイスを接続する | 장치를 연결하세요 | 連接您的設備 | 连接您的设备

FUNCTIONS

FONCTIONS | FUNCIONES | FUNKTIONEN | FUNZIONI |
FONKSİYONLAR | FUNKCJE | FUNÇÕES | ФУНКЦИИ |
機能 | 기능 | 功能 | 功能



1. USB-C Connector

Connecteur USB-C | Conector USB-C | USB-C- Anschluss |
Connettore USB-C | USB-C Konektörü | Złącze USB-C | Conector USB-C | USB-C Разъем | USB-C コネクタ | USB-C 커넥터 | USB-C 連接器 | USB-C 连接器

2. Power LED Indicator

Indicateur d'alimentation LED | Indicador LED de encendido | LED-Betriebsanzeige | Indicatore di alimentazione a LED | LED güç göstergesi | Wskaźnik LED zasilania | LED indicador de energia | Светодиодный индикатор питания | LED 電源インジケータ | LED 전원 표시기 | LED 電源指示燈 | LED 電源指示灯

3. SD & Micro SD Card Readers (UHS-I)

Lecteurs de cartes SD et Micro SD | Lectores de tarjetas SD y Micro SD | SD- und Micro SD-Kartenleser | Lettori di schede SD e Micro SD | SD & Micro SD Kart Okuyucular | Czytniki kart SD i Micro SD | Leitores de cartões SD e Micro SD | Устройства для чтения карт SD и Micro SD | SD & Micro SD 카드 리더기 | SD 및 Micro SD 카드 리더기 | SD 和 Micro SD 读卡器 | SD 和 Micro SD 读卡器

4. 3x USB-A 3.0 Ports

Ports USB-A 3.0 | Puertos USB-A 3.0 | USB-A 3.0-Anschlüsse | Porte USB-A 3.0 | USB-A 3.0 Bağlantı Noktaları | Porty USB-A 3.0 | Portas USB-A 3.0 | Порты USB-A 3.0 | USB-A 3.0 포트 | USB-A 3.0 포트 | USB-A 3.0 端口 | USB-A 3.0 端口

IMPORTANT

IMPORTANT | IMPORTANTE | WICHTIG | IMPORTANTE
| ÖNEMLI | WAŻNY | IMPORTANTE | ВАЖНО | 重要 | 重要 | 重要事項 | 注意

• USB-A ports are for data purposes only and do not support charging.

• Les ports USB-A sont uniquement destinés à des fins de données et ne prennent pas en charge le chargement.

• Los puertos USB-A son solo para uso de datos y no admiten carga.

• USB-A-Anschlüsse dienen ausschließlich Datenzwecken und unterstützen kein Aufladen.

• Le porte USB-A sono solo a scopo dati e non supportano la ricarica.

• USB-A bağlantı noktaları yalnızca veri amaçlıdır ve şarjı desteklemez.

• Porty USB-A służą wyłącznie do przesyłania danych i nie obsługują ładowania.

• As portas USB-A são apenas para fins de dados e não suportam carregamento.

• Порты USB-A предназначены только для передачи данных и не поддерживают зарядку.

• USB-A 포트는 데이터 목적의みに 사용되며 충전은 지원하지 않습니다.

• USB-A 포트는 데이터 용도로만 사용되며 충전을 지원하지 않습니다.

• USB-A 端口僅用於數據用途，不支持充電。

• USB-A 端口仅用于数据用途，不支持充电。

• USB-A ports not compatible with Apple USB SuperDrive or other CD readers.

• Ports USB-A non compatibles avec Apple USB SuperDrive ou autres lecteurs de CD.

• Los puertos USB-A no son compatibles con Apple USB SuperDrive u otros lectores de CD.

• USB-A-Anschlüsse sind nicht kompatibel mit Apple USB SuperDrive oder anderen CD-Lesegeräten.

• Porte USB-A non compatibili con Apple USB SuperDrive o altri lettori CD.

• USB-A bağlantı noktaları, Apple USB SuperDrive veya diğer CD okuyucularla uyumlu değildir.

• Porty USB-A nie są kompatybilne z Apple USB SuperDrive lub innymi czytnikami CD.

• Portas USB-A não compatíveis com Apple USB SuperDrive ou outros leitores de CD.

• Порты USB-A несовместимы с Apple USB SuperDrive или другими устройствами чтения компакт-дисков.

• USB-A 포트는 Apple USB SuperDrive 또는 다른 CD 리더기와 호환성이 없습니다.