


S A T E C H I


# SLIM LX3 WIRED KEYBOARD



**USER MANUAL**

**ENGLISH**


# FUNCTIONS



1. USB-C Connector with USB-C to USB-A Adapter
2. Function Lock
3. Media / Functions Keys
4. Fn Key
5. Caps Lock LED Indicator
6. Num Lock Key
7. WIN Modifier Keys (switch in WIN mode)
8. MAC Modifier Keys (switch in MAC mode)
9. Numeric Pad
10. MAC / WIN Switch
11. Power / Charging LED

## PLUG & PLAY

Plug into USB-C or USB-A port and the keyboard will be detected by the device.



## LED INDICATORS

- ON/OFF – turns green for 3 seconds and turns off.
- Caps Lock – White LED turns on when Caps Lock is enabled.












## HOT KEY FUNCTION AND SUPPORT TABLE

The key function is based on the OS selected via the MAC/WIN switch. For buttons F1 - F13 press Fn + Esc to enable the function.

	MAC	WINDOWS
☀ F1	Decrease Display Brightness	
☀ F2	Increase Display Brightness	
☰ F3	Mission Center	Task View
☰☰ F4	Spotlight Search - App	App Switcher
🔍 F5	Spotlight Search	Windows Search
🗣 F6	Dictation	

## MAC

## WINDOWS

 F7	Screenshot	
 F8	Previous Track	
 F9	Play / Pause	
 F10	Next Track	
 F11	Mute	
 F12	Volume Down	
 F13	Volume Up	
	Emoji	
	Do Not Disturb	N/A
	Screen Lock	
esc 	Single Press Esc / Fn + Lock Fn Keys	