


S A T E C H I


SLIM EX3 WIRELESS KEYBOARD



USER MANUAL

ENGLISH

FUNCTIONS



1. Function Lock

2. Media / Functions Keys

3. Fn Key

4. Bluetooth Device Keys with LED Indicator

5. 2.4GHz Receiver Key with LED

6. Caps Lock LED Indicator

7. Num Lock Key

8. WIN Modifier Keys (switch in WIN mode)

9. MAC Modifier Keys (switch in MAC mode)

10. Numeric Pad

11. 2.4GHz Receiver USB-C

12. Battery Cover with Screw

13. MAC / WIN Switch

14. ON / OFF Switch

15. Power / Charging LED

16. USB-C Charging Port

HOT KEY FUNCTION AND SUPPORT TABLE

The key function is based on the OS selected via the MAC/WIN switch. For buttons F1 - F13 press Fn + Esc to enable the function.

	MAC	WINDOWS
 F1	Decrease Display Brightness	
 F2	Increase Display Brightness	
 F3	Mission Center	Task View
 F4	Spotlight Search - App	App Switcher
 F5	Spotlight Search	Windows Search
 F6	Dictation	
 F7	Screenshot	
 F8	Previous Track	
 F9	Play / Pause	
 F10	Next Track	
 F11	Mute	
 F12	Volume Down	
 F13	Volume Up	
	Emoji	
	Do Not Disturb	N/A

	Screen Lock
esc 	Single Press Esc / Fn + Lock Fn Keys

HOW TO USE

ON / OFF

To turn the keyboard on or off, move the switch on the top of the device to the "on" position. The green power indicator light will turn on for about 3 seconds.

PAIRING YOUR DEVICES

1. Press and hold one of the three Bluetooth Keys or the 2.4GHz receiver key for 3 seconds to assign a device. Once paired, indicator light will go solid for 1 sec and then turn off.
2. On the host device, look for "EX3 Keyboard" in the Bluetooth Setting, choose "Connect" to pair. The white LED will stop blinking, indicating a successful pairing. Repeat process to add up to 3 Bluetooth devices. If you are connecting to the 2.4Ghz receiver, ensure it is securely connected to the host device before you start the pairing process.

Note:

- After 60 minutes of non-operation, the keyboard will go to sleep mode. Please press any key to wake up.
- To switch between Bluetooth 1, Bluetooth 2, Bluetooth 3, and the 2.4GHz receiver, press the dedicated pairing key to switch devices.

LED INDICATORS

ON/OFF - turns green for 3 seconds and turns off.

Low Battery - flashes red when it's low battery.

Charging - turns red when it's charging.

Fully Charged - turns green and stays green.

Caps Lock - White LED turns on when Caps Lock is enabled.

CHARGING YOUR KEYBOARD

1. When the battery is low, the power indicator will flash red. Connect the keyboard to a computer or USB-C wall adapter using the included USB-C charging cable.
2. Charge the keyboard for 2 to 3 hours, or until the red charging LED light turns green.

Note: The keyboard is designed to accept a low wattages so any wall charger 5W or greater is acceptable.

2.4GHz USB-C DONGLE CONNECTION

1. Remove the included 2.4GHz USB-C receiver dongle from the back of your keyboard.
2. Connect it to the USB-C port on your device.
3. The EX3 keyboard should now be connected to the 2.4GHz receiver.

Note: If the keyboard does not connect automatically to the 2.4GHz receiver, it may be necessary to put the keyboard in pairing mode. First, remove the 2.4GHz receiver from the device. Hold down the 2.4GHz dongle icon on the keyboard to start the pairing process. Insert the 2.4Ghz receiver into the device. This will allow the keyboard to find the 2.4GHz dongle and connect.

SAFETY INSTRUCTIONS

Warning: Fire, electric shock, damage to keyboard device could occur if the following instructions are not obeyed.

- 1.** Keep away from microwave radiation sources.
- 2.** Do not place heavy objects on this product.
- 3.** No dropping and bending.
- 4.** Keep away from oil, chemical, or organic solvents.