Dimension: 75 x 135 mm

OUTSIDE

IMPORTANT

IMPORTANT | IMPORTANTE | WICHTIG | IMPORTANTE | ÖNEMLI | WAŻNE | IMPORTANTE | ВАЖНО | 重要 | 중요 | 重要 | 重要

• Connected USB devices should not exceed an input current of 900mA.

• Les périphériques USB connectés ne doivent pas dépasser un courant d'entrée de 900 mA.

• Los dispositivos USB conectados no deben superar una corriente de entrada de 900 mA.

• Angeschlossene USB-Geräte dürfen einen Eingangsstrom von 900 mA nicht überschreiten.

• I dispositivi USB collegati non devono superare una corrente in ingresso di 900 mA.

• Bağlı USB cihazları 900 mA giriş akımını aşmamalıdır.

• Podłączone urządzenia USB nie powinny przekraczać prądu wejściowego 900 mA.

• Os dispositivos USB ligados não devem exceder uma corrente de entrada de 900 mA.

• Подключённые USB-устройства не должны превышать входной ток 900 мА.

• 接続されるUSBデバイスは、入力電流900mAを超えないでください。

• 연결된 USB 디바이스는 입력 전류 900mA를 초과하지 않아야 합니다.

• 連接的 USB 裝置不得超過輸入電流 900mA。

• 连接的 USB 设备不得超过输入电流 900mA。

• Safely eject data storage devices prior to disconnecting adapter.

• Éjectez en toute sécurité les périphériques de stockage de données avant de débrancher l'adaptateur.

• Expulsar de forma segura los dispositivos de almacenamiento de datos antes de desconectar el adaptador.

• Speichermedien sicher auswerfen, bevor Adapter getrennt wird.

• Espellere in sicurezza i dispositivi di archiviazione prima di scollegare l'adattatore.

• Adaptörü çıkarmadan önce veri depolama cihazlarını güvenle çıkarın.

• Bezpiecznie wysuń urządzenia pamięci masowej przed odłączeniem adaptera.

• Ejetar em segurança os dispositivos de armazenamento de dados antes de desligar o adaptador.

• Безопасно извлеките устройства хранения данных перед отключением адаптера.

• アダプターを外す前に、ストレージデバイスを安全に取り出してください。

• 어댑터를 분리하기 전에 저장 장치를 안전하게 꺼내십시오.

• 在拔除轉接器前，請先安全退出儲存裝置。

• 在拔出适配器前，请先安全弹出存储设备。

• Insert the microSD card with the metal pins facing down. Insert the SD card with the metal pins facing up.

• Insérez la carte microSD avec les broches métalliques vers le bas. Insérez la carte SD avec les broches métalliques vers le haut.

• Insertar la tarjeta microSD con los pines metálicos hacia abajo. Insertar la tarjeta SD con los pines metálicos hacia arriba.

• microSD-Karte mit den Metallkontakten nach unten einlegen. SD-Karte mit den Metallkontakten nach oben einlegen.

• Inserire la scheda microSD con i pin metallici rivolti verso il basso. Inserire la scheda SD con i pin metallici rivolti verso l'alto.

• Metal pinler aşağı bakacak şekilde microSD kartı takın. Metal pinler yukarı bakacak şekilde SD kartı takın.

• Włóż kartę microSD metalowymi pinami do dołu. Włóż kartę SD metalowymi pinami do góry.

• Inserir o cartão microSD com os pinos metálicos voltados para baixo. Inserir o cartão SD com os pinos metálicos voltados para cima.

• Вставьте карту microSD металлическими контактами вниз. Вставьте карту SD металлическими контактами вверх.

• microSDカードは金属ピンが下向きになるように挿入してください。SDカードは金属ピンが上向きになるように挿入してください。

• microSD 카드는 금속 핀이 아래를 향하도록 삽입하십시오. SD 카드는 금속 핀이 위를 향하도록 삽입하십시오.

• 將 microSD 卡的金屬接點朝下插入。將 SD 卡的金屬接點朝上插入。

• 将 microSD 卡的金属接点朝下插入。将 SD 卡的金属接点朝上插入。



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

NEED HELP?

BESOIN D'AIDE ? | ¿NECESITA AYUDA? | HILFE BENÖTIGT? | HAI BISOGNO DI AIUTO? | YARDIMA MI IHTIYACINIZ VAR? | POTRZEBUJESZ POMOCY? | PRECISA DE AJUDA? | НУЖНА ПОМОЩЬ? | お困りですか? | 도움이 필요하십니까? | 需要協助嗎? | 需要帮助吗?

Manufacturer:
10637 Scripps Summit Ct
San Diego, CA 92131, USA
+1 858 268 1800
support@satechi.com
www.satechi.com

EU Authorized Representative:
Chemical Inspection and Regulation Service Limited
CIRS, Regus Harcourt Centre
Dublin, Ireland, D02 HW77
+353 1 477 3710

UK Representative:
Chemical Inspection and Regulation Service UK Ltd.
Unit 536, Salisbury House
London Wall, London, EC2M 5SQ
+44 20 3289 6395

SATECHI

USB-C PRO HUB SLIM ADAPTER

USER MANUAL




Manuel de l'utilisateur | Manual de usuario | Bedienungsanleitung | Manuale utente | Kullanım kılavuzu | Instrukcja obsługi | Manual do utilizador | Руководство пользователя | 取扱説明書 | 사용자 설명서 | 使用者手冊 | 用户手册

INSIDE

PLUG & PLAY

CONNECTER ET UTILISER | CONEXIÓN Y USO | ANSCHLIEßEN UND VERWENDEN | COLLEGARE E USARE | BAĞLA VE KULLAN | PODŁĄCZ I UŻYWAJ | LIGAR E USAR | ПОДКЛЮЧИТЬ И ИСПОЛЬЗОВАТЬ | 接続して使用する | 연결하여 사용하십시오 | 連接並使用 | 连接并使用



1. Connect to a laptop


Branchez à un ordinateur portable | Conectar a un portátil | Mit einem Laptop verbinden | Collegare a un portatile | Bir dizüstü bilgisayara bağlayın | Podłącz do laptopa | Ligue a um portátil | Подключите к ноутбуку | ノートパソコンに接続してください | 노트북에 연결하십시오 | 連接至筆記型電腦 | 连接至笔记本电脑

2. Connect your devices

Branchez vos appareils | Conectar los dispositivos | Geräte verbinden | Collegare i dispositivi | Cihazlarınızı bağlayın | Podłącz swoje urządzenia | Ligue os seus dispositivos | Подключите ваши устройства | デバイスを接続してください | 디바이스를 연결하십시오 | 連接您的裝置 | 连接您的设备

FUNCTIONS

FONCTIONS | FUNCIONES | FUNKTIONEN | FUNZIONI | FONKSİYONLAR | FUNKCJE | FUNÇÕES | ФУНКЦИИ | 機能 | 기능 | 功能 | 功能



1. Dual USB-C Connectors

Connecteurs USB-C doubles | Conectores USB-C dobles | Doppelte USB-C-Stecker | Connettori USB-C doppi | Çift USB-C konnektörleri | Podwójne złącza USB-C | Conectores USB-C duplos | Двойные разъёмы USB-C | デュアルUSB-Cコネクター | 듀얼 USB-C 커넥터 | 雙 USB-C 連接器 | 双 USB-C 连接器

2. USB4 Pass-Through Port (40Gbps) (100W PD) (6K/60Hz)

Port USB4 pass-through | Puerto USB4 pass-through | USB4-Durchgangsanschluss | Porta USB4 pass-through | USB4 geçiş portu | Port USB4 Pass-Through | Porta USB4 pass-through | Сквозной порт USB4 | USB4パススルーポート | USB4 패스스루 포트 | USB4 直通連接埠 | USB4 直通端口

3. LED Indicator

Indicateur LED | Indicador LED | LED-Anzeige | Indicatore LED | LED göstergesi | Wskaźnik LED | Indicador LED | Светодиодный индикатор | LEDインジケーター | LED 표시등 | LED 指示燈 | LED 指示灯

4. HDMI Video Port (4K@60Hz)

Port vidéo HDMI | Puerto de vídeo HDMI | HDMI-Videoanschluss | Porta video HDMI | HDMI görüntü çıkışı | Port wideo HDMI | Porta de vídeo HDMI | Видеопорт HDMI | HDMI映像ポート | HDMI 비디오 포트 | HDMI 視訊連接埠 | HDMI 视频端口

5. 2× USB-A Data Ports (10Gbps)

Ports de données USB-A | Puertos de datos USB-A | USB-A-Datenanschlüsse | Porte dati USB-A | USB-A veri portları | Porty danych USB-A | Portas de dados USB-A | Порты данных USB-A | USB-Aデータポート | USB-A 데이터 포트 | USB-A 資料埠 | USB-A 数据端口

6. SD & microSD Card Slots (UHS-I)

Logements pour cartes SD et microSD | Ranuras para tarjetas SD y microSD | SD- und microSD-Kartensteckplätze | Slot per schede SD e microSD | SD ve microSD kart yuvaları | Gniazda kart SD i microSD | Ranhuras para cartões SD e microSD | Слоты для карт SD и microSD | SD/microSDカードスロット | SD 및 microSD 카드 슬롯 | SD 與 microSD 卡插槽 | SD 和 microSD 卡插槽

7. USB-C Data Port (10Gbps)

Port de données USB-C | Puerto de datos USB-C | USB-C-Datenanschluss | Porta dati USB-C | USB-C veri portu | Port danych USB-C | Porta de dados USB-C | Порт данных USB-C | USB-Cデータポート | USB-C 데이터 포트 | USB-C 資料埠 | USB-C 数据端口

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

CE DECLARATION OF CONFORMITY

Satechi declares that this product is in compliance with the essential requirements and other relevant provisions of applicable EC directives. For Europe, a copy of the Declaration of Conformity for this product may be obtained by visiting https://satechi.com/pages/doc-1

WEEE Information

According to the WEEE (Waste Electrical and Electronic Equipment) Directive, do not dispose of this product as household waste or commercial waste. Waste electrical and electronic equipment should be appropriately collected and recycled as required by practices established for your country. For information on recycling of this product, please contact your local authorities, your household waste disposal service, or the shop where you purchased the product.

CAN ICES(B)/NMB(B)
This Class B digital apparatus complies with Canadian ICES(B). (Cet appareil numérique de la Classe B conforme à la norme NMB(B) du Canada).

AUSTRALIAN CONSUMER LAW
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

SKU: ST-HUCPHSD | ST-HUCPHSM | ST-HUCPHSS

R-R-EDO-ST-HUCPHSM