



# Wireless Smart Keypad

Calculator + Number Keypad

# User Manual

ST-WKP31

## Introduction

Thank you for purchasing the Satechi Wireless Smart Keypad! This sleek aluminum keypad looks beautiful and is a perfect companion to any computer. This user manual will show you how to set up your Smart Keypad for wireless use, as well as go over its functions.

### Calculator Mode

Use the Smart Keypad as a normal calculator, with Memory and Backspace functions.

### Keypad Mode

Use the Smart Keypad as a numberpad to type numbers and equations quickly.

## Specifications

Model	ST-WKP31
Frequency Range	ISM Band 2.4GHz
Bluetooth Version	3.0 HID, Class 2
Power Supply	AAA x2
Connecting Time	60 sec
Sleep	10 min
LED	Green: Boot & Pairing / Red: Battery Check & Low Battery
Range	~30ft
Battery Life	~6 months (based on 1 hour of usage/day)

## Contents

- Satechi Wireless Smart Keypad
- User Manual
- AAA Battery x2

## System Requirements

### Hardware

- Bluetooth-enabled computer

### Operating System

- MacOSX v10.4.6 or later
- Windows XP/Vista/7/8

## Battery

Insert the 2 AAA batteries into the battery compartment on the back of the keypad before usage. Ensure that the positive and negative terminals of the batteries and compartment are matched.

CAUTION: Risk of explosion if incorrect battery type is inserted. Please recycle batteries properly.

## Keys



### Rounding System Indicator

**F:** floating decimal system, displays value without rounding


**0, 2, 4:** number of displayed decimal places

**A:** "Add Mode" automatically adds a decimal point and two decimal places to all values. Useful when performing calculations in dollars or other currency.

Display	Function
<b>-MINUS</b>	Indicates negative value
<b>MEMORY</b>	Independent memory indicator
<b>ERROR</b>	Indicates an error
<b>'</b>	3-digit separator (apostrophe)
<b>CALC</b>	Indicates calculator mode
<b>KEYPAD</b>	Indicates keypad mode
<b>GT</b>	Grand total

Key	Function
<b>M+</b>	Adds current display from content of memory
<b>M-</b>	Subtracts current display from content of memory
<b>MRC</b>	First press: transfers contents of memory to display Second press: clears memory
<b>DECI</b>	Specifies number of decimal places for rounding
<b>+ / -</b>	Switches sign of displayed value positive (+) or negative (-)
<b>%</b>	Use with arithmetic operator keys to perform percent function
<b>MODE</b>	Change between calculator and keypad modes
<b>SEND</b>	Send calculation result to PC (when typing)

## Rear Buttons




- 1: Battery cover
- 2: On / Off switch
- 3: Connect button (used for pairing)
- 4: Reset (resets all paired devices and settings)
- 5: Mac / PC switch (set switch before pairing to appropriate device)

## Bluetooth Pairing: Mac


1. Turn the power switch on the back of the keypad to the ON position.
2. Press the Connect button - The LED light will blink green indicating it is in pairing mode.
3. Access your Mac's Bluetooth settings by clicking the Bluetooth icon on the desktop or in the system bar. Select "Turn Bluetooth On" to activate the Bluetooth function.
4. Scroll down the list and select "Set up Bluetooth Device..."
5. The Bluetooth Setup Assistant will begin - follow the on-screen instructions.
6. Press the Connect button on the back of the keypad to put it into pairing mode. Select "ST-WKP31" from the list and click continue to proceed with setup.

## Bluetooth Pairing: Mac

7. Your Mac will generate a passkey - enter these numbers on the keypad and press the Enter button.



8. Your Smart Keypad is ready to be used.



## Safety

*To prevent damage to your product or injury to yourself or others, please read the following safety precautions in their entirety before using equipment.*

- Keep batteries away from children. If swallowed, contact a doctor immediately.
- A battery should be properly disposed of according to local regulations.
- If not disposed of properly, batteries can be harmful. Protect the environment by taking exhausted batteries to authorised disposal stations.
- Do not expose to high temperatures.
- Do not disassemble.
- Do not allow metal objects to contact or short-circuit the battery terminals.
- Do not incinerate or expose to fire.
- Do not expose to water
- Risk of explosion if battery is replaced by an incorrect type.
- Turn device off immediately in even of a malfunction

## Compliance

### FCC CLASS B INFORMATION:

This device complies with part 15 of the FCC results. Operation is subject to the following two conditions:  
1. This device may not cause harmful interference and  
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1.1. Reorient or relocate the receiving antenna
- 1.2. Increase the separation between the equipment and receiver
- 1.3. Connect the equipment into an outlet on a circuit difference from that to which the received is connected
- 1.4. Consult the dealer or an experience radio/TV technician for help

Changes or modifications not expressly approved by the manufacturer could void the user's authority operate the equipment.

## Support

### LIMITED WARRANTY:

Satechi warrants this product to be free from defects in materials and workmanship for 1 year. If this product is found to be defective within that time, we will repair or replace it. This warranty does not cover accidental damage, wear and tear, or consequential or incidental loss. Under no conditions is Satechi liable for loss of, or damage to devices; nor loss of, or damage to, programs, records, or data; nor any consequential or incidental damages, even if Satechi has been informed of their possibility. This warranty does not affect your statutory rights.

### SUPPORT:

If you have any questions, comments, or concerns about your Satechi product, please contact us first.

Phone: 858-268-1800  
Email: sales@satechi.com  
www.satechi.net